

RESET CONFIG

Recall Defaults



CONFIGURATION SIMULATION CLAVIER

Enter/Exit Configuration Mode



France Keyboard



Enter/Exit Configuration Mode



CONFIGURATION MODE LECTURE CODE BARRE

Enter/Exit Configuration Mode



Enable USB Serial Emulation Mode



Enter/Exit Configuration Mode

